APPLICATION

NYU Langone Health

PURPOSE

To protect personnel and property from all federal (e.g., Occupational Safety and Health Adminis
1910 Subpart Q and 1926 Subpart J), state, and local regulations, and Nati
Protection Association (NFPA) standards related to hot work**.**

POLICY

1.0 Application

NYU Langone Health (NYULH) refers to the NYU Langone Health S
Langone Hospitals, NYU Grossman School of Medicine, NYU Long I
Medicine, the Family Health Centers at NYU Langone, and all entities
of them.

This policy applies to:

4 All indoor and outdoor areas of all NYULH owned and leased facilities

- NYC – FDNY G-60 certificate of fitness. For structural welding, NYC DoB license
- Nassau County – Nassau County Welding/Cutting certificate of fitness
- Suffolk County – FDNY G-60 or Nassau County Welding/Cutting certificate of fitness, as well as any Town requirements

Fire watch -

- NYC – FDNY F-60 certificate of fitness
- Nassau and Suffolk County – FDNY F-60 certificate of fitness or NFPA Hot Work

Competent person means a person who is capable of identifying existing and predictable hazards in the surroundings, or working conditions which are unsanitary, hazardous or dangerous to workers, and who has authorization to take prompt corrective measures to eliminate them.

Controlling contractor (Contractor) means a prime contractor, general contractor, construction manager or any other legal entity, which has the overall responsibility for the construction of the project (e.g., its planning, quality, and completion).

Hot work means work which produces flame, sparks, slag (such as cutting, welding, burning, grinding, brazing, soldering, or similar operations) or heat capable of initiating a fire or explosion.

Hot work permit (permit) means a permit generated by NYULH's online hot work permitting system or, where authorized by this policy (see exception in Responsibilities section 5.5), a comparable permit whose use has been approved by Environmental Health and Safety (EH&S).

3.0 Alternatives to hot work and risk reduction

3.1 Due to the hazards hot work poses, work shall be designed and planned to eliminate risk where feasible. Alternatives include:

- performing hot work offsite
- mechanical fastening or bolting
- screw, flanged or clamped pipe
- mechanical shears or pipe cutter
- cold-apply roofing
- water jet

3.2 Where hot work cannot be completely eliminated, less hazardous methods shall be employed (for example, use of a reciprocating saw versus a torch) or the hot work shall be performed outdoors at grade or in a dedicated, controlled indoor area, where feasible.

4.0 Planning of high-risk hot work

4.1 Hot work involving any of the following shall be planned with the campus Safety Officer, and EH&S:

Safety Policy Manual

Policy 143

Policy: Hot Work Program

P

Safety Policy Manual

- Properly transporting compressed gas cylinders out of the building (contractors) or to their approved storage location (staff) when not in use and at the end of each work day.
- Notifying their foreperson or the controlling contractor when post hot work inspections are complete.
- Immediately notifying their foreperson or controlling contractor of any injuries, incidents, or other problems encountered during hot work.
    - Injured employees shall be taken to Occupational Health Services or the nearest Emergency Department for treatment and an incident report completed.
    - Injured contractor personnel shall be taken to the nearest Emergency Department for treatment with a controlling contractor incident report completed.

5.7 The **hot worker** is also responsible for:

- Inspecting the date stamp on compressed gas cylinders to confirm certification within required time period (e.g. oxygen 5 years, acetylene 10 years)
- Installing a UL listed flashback arrestor with check valve at both the torch and regulator for all single and dual gas torch operations
- Properly assembling and inspecting hot work equipment for loose connections, damage and leaks (using soapy water) prior to use.
- Securing all compressed gas cylinders upright in a cart or carrier/stand and keeping them back a safe distance from hot work
- Ensuring that a fume extractor (“smoke eater”) or appropriate exhaust ventilation is in use at the point of the hot work
- Turning off the electric welder and compressed gas cylinders when unattended, not in use and at the end of each work day
- Wearing appropriate protective clothing and equipment

5.8 The **fire watch** is also responsible for:

- Performing no other responsibilities when functioning as a fire watch.

6.2 Hot work which involves the use of propane (>16.4 ounces), compressed natural gas or liquid oxygen shall be approved by, and planned with EH&S.

6.3 Prior to performing hot work on metals that produce toxic fumes (e.g., galvanized steel, stainless steel, aluminum), a job hazard analysis (JHA) is required to ensure compliance with OSHA 1926.353(c) and OSHA Subparts D and E.

6.4 Prior to performing hot work on a painted metal surface, the PM or Manager shall arrange for the paint to be tested for lead. Hot work shall not to be performed on lead-containing surfaces.

6.5 The use of torch down or other hot work methods on roofs is prohibited unless specifically reviewed and approved by NYULH RED+F leadership and EH&S. Personnel shall not perform hot work on a roof constructed of combustible materials (e.g., wood, insulation board) or where exposed combustible materials are present. See NYULH Construction Safety Requirements policy (Sections 11.30 and 11.31).

6.6 Personnel shall only perform hot work on medical gas lines and in bulk oxygen storage areas after the required shutdowns and purging of piping and vessels are complete. This work shall be planned with Facilities, building management and EH&S.

6.7 Prior to performing any hot work on a tank or vessel that was pressurized or formerly contained a combustible, flammable or toxic solid, liquid or gas, a JHA shall be completed and certification of proper depressurization, purging and cleaning of the tank or vessel obtained.

6.8 Smoke or odor producing hot work shall only be performed where an operable smoke eater or proper exhaust ventilation is present at the point of the work. The exhaust ventilation discharge shall be reviewed with EH&S.

6.9 Personnel performing hot work at height shall do so from a stable work platform with guardrail protection (e.g., scaffold or aerial lift), not a ladder (see Safety Policy 163).

6.10

Requirement